

# LOW PROFILE DOG WASTE STATION WITH ROUND CAN

## Parts List:

- Can (1)
- Post (1)
- Dispenser (1)
- Dispenser Keys (2)
- Hardware Pack (1)
- 400 BAGS
- 25 CAN LINERS

## Included Hardware:

- A** 3" Bolt (5)
- B** Flat Washer (10)
- C** Hex Nuts (5)



GALVANIZED SQUARE POST\* (1)  
\*2 Post Sections 47" Each



400 BAGS



DISPENSER KEYS (2)



25 CAN LINERS



CAN (1)



**PLEASE BE SURE TO  
TIGHTEN ALL NUTS  
AND BOLTS SECURELY**

## ASSEMBLY INSTRUCTIONS

- 1. ALWAYS CHECK** for buried services (electric, water, gas, phone, cable) before digging. Dig a post hole 14" deep. Pour in concrete.
- 2. ASSEMBLE THE 2-PIECE POST** with 18" overlap. Use one 3" bolt (A) to secure the 2 sections together. Set and level the post in concrete footing. Allow cement to firmly set-up before attaching can and dispenser to post.
- 3. ATTACH CAN:** Install 5" above ground; thread the 2 bolts (A) with 2 flat washers (B) through the can from the inside. Line up the bolts with holes in the post and tighten with nuts (C).
- 4. INSTALL THE DISPENSER** 13" above the top of the can. Be sure to place washers (C) on the bolts as you bolt from the inside of the dispenser through to the post. Secure to post with nuts and washers.
- 5. FILL DISPENSER** with bags – Install Can Liner.

