

Interior Grille

for Andersen® 200 Series
Tilt-Wash Double-Hung Windows

Parts Included
(1) Grille
(1) Instruction Sheet

Tools Required
• Window Channel
• Cleaning Tool

INSTALLER: Please leave this guide with the building owner to use for future reference. For ease of installation and continuous enjoyment of your Andersen product, please read and follow the instructions in this guide completely. You may direct any questions about this or other products to your local Andersen dealer. Andersen dealers can be located in the Yellow Pages under Windows. Thank You for choosing Andersen.

1. Prepare Unit and Interior Grille

- Clean glass and sash before Grille installation.
- Remove Grille from packaging and make sure Grille Fasteners are in each end. Push all Grille Fasteners to full open position.



2. Apply Grille on Sash

- Center Grille vertically and horizontally on glass and apply slight pressure on both ends of a single vertical Grille Member to begin engagement of Grille Fasteners. Repeat for remaining Grille Members.
- Apply firm pressure to Grille Member top until Grille Fasteners are seated tight against glass. Make sure all Grille Fasteners are properly engaged between glass and sash lip.




Illustration Code: 9802296 Revised 01/02/02