

§ 82-233. Testing of assemblies. (Ord. No. B-641, § 1(7-102), 2-10-2000)

- (a) The property owner or his lessee shall have the backflow prevention assembly tested by a state certified backflow prevention assembly tester who is approved by the director:
 - (1) Immediately after installation;
 - (2) Immediately after the assembly is moved;
 - (3) A minimum of once a year for all high health hazard connections;
 - (4) Every six months for any premises that has a reduced pressure principle backflow prevention assembly as point-of-use protection without high-hazard premises isolation protection;
 - (5) Every six months for any premises that has a reduced pressure principle backflow prevention assembly as premises isolation without high-hazard point-of-use protection;
 - (6) Prior to re-occupancy of premises that have been vacated and unoccupied for one year; and
 - (7) Immediately after repair.
- (b) The director may deem it necessary to test assemblies more frequently than prescribed in subsection (a) of this section.
- (c) The tester shall perform all assembly testing in accordance with city-approved test procedures.
- (d) A water use survey may be conducted at any establishment located in the city which is served by a public water supply or which provides water to the public. Upon determination that the establishment falls under the provisions of this article and requires a backflow prevention assembly, a notice to abate the condition or to install the proper backflow prevention assembly shall be issued.
- (e) The city shall not be liable for damage to an assembly that occurs during testing when damage results from metal fatigue or deteriorated metal or when damage occurs under standard testing procedures.
- (f) All results from assembly testing by a certified backflow prevention assembly tester shall be ~~placed on a form that is purchased by the tester from the city at an established fee~~ entered directly by the tester into the City's designated online assembly testing results system.