




North Elevation View SCALE: 1/8"-1'-0"



South Elevation View SCALE: 1/8"-1'-0"



East Elevation View SCALE: 1/8"-1'-0"



West Elevation View SCALE: 1/8"-1'-0"