







REMOVE ONE-WAY SIGN

REMOVE DO NOT ENTER SIGN

REMOVE DO NOT ENTER SIGN AND STOP SIGN

REMOVE NO RIGHT TURN SIGN