



1301 S. Bebe
Wichita, KS 67209

(316) 425-3221

(316) 425-3222 FAX
www.automotiveequipmentinc.com

2-Post Lift Inspection

Inspector: **Eric Kaldenbach**
Manufacturer: **Percision Metal Works**
Serial: **LG 1341 04-93**
Certification Serial #: **---**

Shop: **City of Anthony**
Date: **2/2/2021**
Model: **OH 9000**
Capacity: **9000lbs**
AEI# **---** Bay # **1**

Lift Passes

Lift would pass with repairs

x Lift Fails

Accessibility of Documents

	No Action Required	Action Required	Action Performed	Parts Price	Labor Price
Rated Load Capacity Label	x				
ALI 'Lift it Right' Guide	x		Not present	\$ 40.00	\$ -
2021 Vehicle Lifting Points, Frame Engaging Guide	x		Not present	Included	\$ -
Operations Training Log	x		Not present	Included	\$ -
Inspection Certificate	x		Not present	Included	\$ -
Periodic Maintenance Log	x		Not present	Included	\$ -
Preventative Maintenance Log	x		Not present	Included	\$ -
Check for Lift Safety Labels ALI/WL101	x				

Lift and Bay Inspection

Confirm adequate clearance around lift.	x		
Concrete condition.	x		
Examine all accessible structural components for signs of fatigue, overloading, misuse or abuse including welds.	x		All four arms are sagging beyond safety measures. No parts available to repair
Check for burrs and sharp edges.	x		
Are all nuts and bolts present and secure?	x		

Cables or Chains

Check for debris.	x		
Check for corrosion.	x		
Check for master links.			N/A
Check for wear.	x		

Check for stretching.

X		
X		
X		
X		

Check for damage.

Check tension.

Locks synchronized?

Sheaves & Axles

Check for cracks.

X		
X		
X		
X		

Check to see if loose.

Check bushings.

Are sheaves turning freely?

Arms

Check arm pin holes in carriage for excessive wear

	X	
X		
X		
X		

All four arms have excessive wear at the arm pin holes causing the instability in the arms

Is stop bolt present on arm?

Is pad assembly working correctly and not missing retainers?

Do arms move freely in and out?

Arm Restraints

Check for debris and damage to threaded rod or

X		
X		

Do the arm restraints operate smoothly?

Lock Mechanism

Check for debris & damage to latch cable.

X		
X		
X		
X		

Check tension and cable adjustment.

Do locks operate smoothly?

Are safety lock covers present?

Overhead

Check for debris, bowed overhead or loose bolts.

X		
X		

Are cables or hoses tangled or rubbing?

Verify safety shutoff is working properly and no loose, exposed or unstranded wires.

N/A

Hydraulic Steel Lines/Hoses & Cylinders

Check for tight fittings.

X		
	X	

The passenger side cylinder is seeping oil past seals.
Will not hold pressure. No parts available

Check for leaks.

Cylinder Info:

Power Unit

Check fluid level and for contamination.

X		
---	--	--

Check electrical motor switch cover for damaged or exposed wires.

Check lift controls to ensure accessibility, unobstructed view of lift and automatic return to neutral, or off, when released.

Confirm appropriate electric component labeling.

x			
x			
x			

Columns

Check inside columns for debris.

Check columns for square and plumb.

Check anchor bolts torque to 80 ft/lbs.

Check to make sure all hardware is tight & no missing bolts.

Check that grease is present and free of dirt & Slip-On Adapters

Check adapter is not bent or dented. Check pads for excessive contaminatin from oil, rust or dirt.

x			
x			
x			
x			
x			
x			
x			

Customer Printed Name:

Customer Signature:

Total Parts * **Total Labor**

\$ 40.00 \$ -

*Freight is in addition to parts prices quoted.