MEMO



To: Planning Commission

From: Ryan Harris, Staff Planner

Date: September 24, 2021

RE: Santaquin Dentistry and Canyon Creek Orthodontics Additional Sign Request

Santaquin Dentistry and Canyon Creek Orthodontics will be located in Ridley's Pad Site C building and will occupy the west portion of the building. The applicant submitted a sign permit on September 10, 2021 and is proposing four signs. There will be four signs, two on the front (south elevation) and two on the rear (north elevation) of the building. If there is a sign on the rear of the building, Planning Commission approval is needed. The rear of the building on Ridley's Pad Site C is the elevation facing the parking lot. The front of the building is considered the elevation facing Main Street.

Santaquin City Code 11.44.080.E.5 says, "Wall Specified: Buildings or businesses with exposure on the side(s) and front may choose which wall to mount their sign upon. Signs are allowed on the rear of the building with planning commission approval.


The proposed signs meet all requirements found in SCC 10.44.080.E.2. The proposed signs are not considered cabinet signs. The letters are all individually lite and attached to the background. The background will not be lite. The signs also meet all area requirements for the primary and secondary walls.

Recommended Motion: "Motion to approve or deny the proposed Santaquin Dentistry Signs.

Attachments:

1. Proposed Sign Plans

ATTACHMENT 1: PROPOSED SIGN PLAN



FRONT ILLUMINATED CHANNEL LETTERS

.1875" Acrylite White Acrylic

1st Surface Applied Vinyl

Gerber High Performance Translucent Vivid Green (230-156 ■)

High Performance Printed Perforated Vinyl (■)

High Performance Printed Perforated Vinyl (■)

TRIMCAP

1" Jewelite Black Trimcap

RETURNS

3" Deep - .040 Aluminum

Pre-Painted; Alliance Metals Raven Black

.040 Aluminum Backs

ILLUMINATION

White LED

Samsung 9000K

INSTALLATION

Lettering Mounted to 3" Aluminum Raceway


Painted; Satin Finish (Napa 42075)

Project Detail

SCALE 3/8" = 1'0"

Qty: 2 /

Install 43.70 Side Detail SCALE 3/8" = 1'0"



UL LABEL PLACEMENT

WALL SIGNS

FIRST LETTER/CHARACTER: PLACE LABEL ON THE LEFT RETURN. FOLLOWING LETTERS/CHARACTERS: PLACE LABEL ON TOP OR IN A DISCREET PLACE SO THEY ARE NOT SEEN FROM PEDESTRIAN VIEW. ALL LABELS TO BE CENTERED AND STRAIGHT.

FILE PATH: NEW JOBSD / COMPANY NAME / DESIGN / DESIGN NUMBER




ALL ELECTRICAL COMPONENTS TO BE U.L. LISTED, APPROVED AND MARKED PER N.E.C. 600-4. Inspected and labeled in accordance with UL Standards using UL listed parts and methods of installation in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign. The location of the disconnect switch after installation shall comply with Article 600.6(A)(1) of the National Electrical Code.

CLIENT SIGNATURE LANDLORD SIGNATURE

Santaquin Dentistry 400 East Main Street Santaguin, Utah 84655

SD S CL 003-21 09/21/21 SHEET

sa Zane Latimer 801.755.2953



FRONT ILLUMINATED CHANNEL LETTERS

ACES

.1875" Acrylite White Acrylic

1st Surface Applied Plotted Vinyl

Gerber High Performance Translucent Olympic Blue (230-57 ■)

Gerber High Performance Translucent Mango (230-125 ■)

High Performance Printed Perforated Vinyl (■)

TRIMCAP

1" Jewelite Black Trimcap

RETURNS

3" Deep - .040 Aluminum

Pre-Painted; Alliance Metals Raven Black

BACKS

.040 Aluminum Backs

ILLUMINATION


White LED

Samsung 9000K

INSTALLATION

Lettering Mounted to 3" Aluminum Raceway

Painted; Satin Finish (Napa 42075 ■)



SIGN

ALL ELECTRICAL COMPONENTS TO BE U.L. LISTED, APPROVED AND MARKED PER N.E.C. 600-4. Inspected and labeled in accordance with UL Standards using UL listed parts and methods of installation in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign. The location of the disconnect switch after installation shall comply with Article 600.6(A)(1) of the National Electrical Code.

Volts Req'd: 120V Total Amps: 20.0 Circuits Req'd: 1 Client to provide primary electric feed to within 6 feet of sign location.

WALL SIGNS

UL LABEL PLACEMENT



FILE PATH: NEW JOBSD / COMPANY NAME / DESIGN / DESIGN NUMBER

Santaquin Dentistry

400 East Main Street


DESIGN # SD S CL 003-21
DATE 09/21/21

DESIGN # SD S CL 003-21

DATE 09/21/21

SHEET 1.20

SR Zane Latimer 801.755.2953



North Elevation View SCALE 1/8" = 1'0"

SIGN

ALL ELECTRICAL COMPONENTS TO BE U.L. LISTED, APPROVED AND MARKED PER N.E.C. 600-4. Inspected and labeled in accordance with UL Standards using UL listed parts and methods of installation in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign. The location of the disconnect switch after installation shall comply with Article 600.6(A)(1) of the National Electrical Code.

WALL SIGNS

CLIENT SIGNATURE LANDLORD SIGNATURE

FIRST LETTER/CHARACTER: PLACE LABEL ON THE LEFT RETURN. FOLLOWING LETTERS/CHARACTERS: PLACE LABEL ON TOP OR IN A DISCREET PLACE SO THEY ARE NOT SEEN FROM PEDESTRIAN VIEW. ALL LABELS TO BE CENTERED AND STRAIGHT.

FILE PATH: NEW JOBSD / COMPANY NAME / DESIGN / DESIGN NUMBER SD S CL 003-21 Santaquin Dentistry 400 East Main Street 09/21/21

Volts Req'd: 120V Total Amps: 20.0 Circuits Req'd: 1 Client to provide primary electric feed to within 6 feet of sign location.

UL LABEL PLACEMENT

SHEET Santaquin, Utah 84655 sr Zane Latimer 801.755.2953